tissin

Smart Valve Positioner TS700 Series **Instruction Manual**

















Tissin Co.,Ltd.

Ver. PM-TS700EN-10/2024

Table of Contents

1	Intr	oduction4			
	1.1	General information for the user 4			
	1.2	Limited warranty and disclaimer 4			
	1.3	Requirement for safety 5			
	1.4	Basic safety instructions for use in Ex area 6			
	1.5	Conditions to maintain intrinsically safety (Ex i) 6			
	1.6	Certificate 7			
2	Pro	duct Description8			
	2.1	Function 8			
	2.2	Features 8			
	2.3	Options 8			
	2.4	Applications 8			
	2.5	Label 9			
	2.6	Product Code 10			
	2.7	Specification 1			
	2.8	Structure 12			
		2.8.1 External structure 12			
		2.8.2 Internal structure 13			
	2.9	System configuration 14			
	2.10	Principle of operation			
	2.11	Product Dimension 15			
		2.11.1 TS700 standard type 15			
		2.11.2 TS700 with limit switch type 15			
		2.11.3 TS700 feedback shaft connection 15			
3	Ins	tallation 16			
	3.1	Before installation 16			
	3.2	TS700L installation 16			
		3.2.1 Notes on installation 16			
		3.2.2 Effective rotation angle range of feedback lever 17			
		3.2.3 Lever type and dimension 17			
		3.2.4 Bracket Installation 18			
		3.2.5 Dimension after installation 18			
	3.3	TS700R installation 19			
		3.3.1 TS700R installation examples 19			
		3.3.2 TS700R bracket installation components 19			
		3.3.3 TS700R installation steps 20			
	3.4	TS720 Remote type installation 22			
	3.5	Option module Installation 23			

		3.5.1 Position transmitter module(PTM) Installation	23
		3.5.2 HART communication module Installation	23
		3.5.3 Limit switch module Installation	24
		3.5.4 How to adjust limit switch cam	25
	3.6	How to replace Air Filter	26
	3.7	Orifice installation	27
4	Pn	eumatic connection	28
	4.1	Air pressure condition	28
	4.2	Pneumatic port Description	28
	4.3	Air connection	29
		4.3.1 TS700L air connection	29
		4.3.2 TS700R air connection	29
5	Ele	ectrical connection	30
	5.1	Terminal description	30
	5.2	Wiring diagrams	31
		5.2.1 Power and Feedback signal connection	31
		5.2.2 Mechanical Limit switch connection	31
		5.2.3 Proximity Limit switch connection	31
6	Cal	libration	32
	6.1	LCD description	32
	6.2	Button description	33
	6.3	How to quickly perform Auto calibration	34
		6.3.1 Auto calibration Steps	34
	6.4	Software map	35
	6.5	Main menu Description	36
	6.6	Main parameter menu Description	37
	6.7	Submenu Description	38
		6.7.1 TUNNING	38
		6.7.2 PARAMETR	40
		6.7.3 DEVICE P	42
		6.7.4 INFOMATN	45
		6.7.5 DIAGNOST	46
		6.7.6 EMERGNCy	48
7	Err	or code and Troubleshooting	49
	7.1	Error code during Auto calibration	49
	7.2	Error code during operation	51

1 Introduction

1.1 General information for the user

This instruction includes installation, operation, maintenance, and parts information for Tissin TS700 Valve Positioner. Keep these instructions in a location which is easily accessible to every user and make these instructions available to every new owner of the device.

- Installation, commissioning and maintenance of the product can only be performed by trained specialist personnel who have been authorized by the plant operator to do so.
- Before installing or commissioning, be sure to read and thoroughly understand the product manual and operate the product properly.
- Operators must strictly observe the applicable national regulations with regards to installation, function tests, repairs, and maintenance of electrical products.
- Warnings and Cautions must be observed to prevent operator injury or damage to valve parts.

The manual can be altered or revised due to hardware of software upgrades without any prior notice. Please visit our website (www.tissin.co.kr) and check the latest documentation.

1.2 Limited warranty and disclaimer

- This product has been fully inspected and shipped through a thorough quality inspection procedure. The manufacturer warranty period of the product is 18 months after the product is shipped from Tissin in Korea.
- For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- Using the device in a manner that does not fall within the scope of its intended use, disregarding this manual, using under unqualified personnel, or making unauthorized alterations releases the manufacturer from liability for any resulting damage. This renders the manufacturer's warranty null and void.

1.3 Requirement for safety

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. These safety instructions are intended to prevent hazardous situations and/or equipment damage. For the safety, it is important to follow the instructions in the manual.

! WARNING

Failure to observe the warning may result in serious injuries or death.

A CAUTION

Failure to observe this warning may result in damage to the device or personal injury.

⚠ NOTICE

Failure to observe the warning may result in damage to the device or may degrade performance.

⚠ CAUTION

- Only trained and authorized person should operate the machinery and the equipment.
- Do not use this positioner out of the range of its specifications as this can cause failure.
- Do not service or attempt to remove product and machinery/equipment until safety is confirmed.
- Before loosening the pneumatic lines and valves, turn off the pressure and vent the pneumatic lines.
- Observe applicable accident prevention and the safety regulations for electrical equipment.
- Before handling the device or equipment, turn off the power supply and secure it from re-activation.

1.4 Basic safety instructions for use in Ex area

To prevent the risk of explosion, observe not only the basic safety instructions in the respective operating instructions for operation in the Ex area, but also the following.

MARNING

- Observe the applicable safety regulations (also national safety regulations) as well as the general rules of technology for construction and operation.
- Make sure that the device is suitable for the area of use.
- Check the positioner's certified and permitted explosion proof range.
- Close all unnecessary Cable Gland with the locking screws approved by the explosion site.

1.5 Conditions to maintain intrinsically safety (Ex i)

WARNING

- Make sure to connect "Intrinsic safety" type protection device to intrinsically safe circuit only.
- Observe the specifications for the electrical data on the certificate and in technical data.
- In order to maintain intrinsically safe protection, be sure to use a barrier that meets the following specifications.

Barrier specifications	Ui	li	Pi	Ci	Li
Main power	28V	101mA	707mW	0.6nF	6uH
Position transmitter, Alarm1, Alarm2, Limit Switch(Dry contact type)	28V	101mA	707mW	0.6nF	6uH
Limit Switch (Proximity type)	16V	26mA	34mW	30nF	50uH

Note: Please refer to the relevant certificate for details.

1.6 Certificate

This product has obtained a variety of explosion-proof certification and safety level certification. For details, please visit our website and download the corresponding explosion-proof certificate for confirmation.

Certification		Certificate number	Explosion proof grade
IECEX IECEX		IECEx EPS 23.0057X	Ex ia IIC T5/T6 Gb Ex ia IIIC T100°C/T85°C Db IP66
⟨£x⟩	ATEX	EPS 23 ATEX 1 141 X	II 2G Ex ia IIC T5/T6 Gb II 2D Ex ia IIIC T100°C/85°C Db IP66
<u> </u>		2023322307005655	Ex ia IIC T5/T6 Gb Ex ia IIIC T100°C/85°C Db
Ex NEPSI	NEPSI	GYJ23.1300X	Ex ia IIC T5/T6 Gb Ex ia IIIC T100°C/85°C Db
ERC	EAC	RU C-KR.AA71.B.00616/24	0Ex ia IIC T6T5 Ga X
· ·	KCS	2023-065702-01-1	Ex ia IIC T5/T6 Gb
© s	NUO	2023-065696-01-1	Ex ia IIIC T100°C/85°C Db

2 Product Description

2.1 Function

Smart valve positioner TS700 series controls the valve stroke in response to an input signal of 4~20mA DC from the control panel, DCS or calibrator.

2.2 Features

- Fail freeze function
- Zero air consumption when standby signal
- Prevents circuit board corrosion by external air exhaust design
- Built in air filter (5 micron) for protect PIEZO valve
- LCD and 4 button local control
- · Quick and easy calibration
- PST and alarm function
- Built-in self-diagnostic function
- Strong vibration resistance and impact resistance

2.2 Options

Optional functions can be added simply by installing modules.

- Position transmitter (4~20mA DC Feedback signal)
- HART communication (Ver. HART 7)
- Limit switch (Mechanical or Proximity type)
- Remote control type (TS720)

2.4 Applications

TS700 is mounted on a pneumatic control valves and is used for fluid control of industrial parts.

- · Oil and gas
- Chemicals
- Power plant
- Paper
- Water treatment
- Pharmaceutical
- Printing and dyeing processing
- Food and beverage
- Etc.

2.5 Label

SMART POSITIONER

MODEL No. SERIAL No.

EXPLOSION PROOF Ex ia IIC T5/T6 Gb

Ex ia IIIC T100°C/T85°C Db

T5:-40°C ~ +60°C T6:-40°C ~ +40°C EXPLOSION PROOF TEMP.

INGRESS PROTECTION IP66

INPUT SIGNAL 4 ~ 20mA DC

SUPPLY PRESSURE 0.14 ~ 0.7 MPa (1.4 ~ 7 bar)

Ui, Ii, Pi, Ci, Li See Certificate

WARNING - Do not open when an explosive atmosphere is present #397, Seokcheon-ro, Ojeong-gu, Bucheon-si, Gyeonggi-do, Korea

Made in Korea



Item	Description
MODEL No.	Indicate the model number.
SERIAL No.	Indicate the serial number.
OPERATING TEMP.	Indicate the allowable operating temperature.
EXPLOSION PROOF	Indicate the certified explosion proof grade.
EXPLOSION PROOF TEMP.	Indicate the ambient temperature range for the explosion proof. This temperature range must be observed when using in explosion-proof areas.
WEATHER PROOF	Indicate the enclosure grade.
INPUT SIGNAL	Indicates input current signal range.
SUPPLY PRESSURE	Indicate the allowable input supply pressure range.
Ui, Ii, Pi, Ci, Li	Indicate required barrier specification for intrinsically safety circuit configuration. Please refer to the certificate for the detailed specifications.

2.6 Product Code

Model	TS700								
Standard type	TS700								
Remote type	TS720								
Stainless steel 316	TS705								
Motion type	Linear	L							
	Rotary	R							
Acting type	Single		S						
	Double		D						
Explosion proof type	Non-explosion proof			N					
	ATEX & IECEx			Α					
	CCC & NEPSI			С					
	EAC			Е					
	KCs			K					
Connection type	Conduit entry A	ir co	nnect	tion	_				
	G(PF)1/2	PT1	/4		1				
	G(PF)1/2	NPT	1/4		2				
	NPT1/2	NPT	1/4		3				
	M20	NPT	1/4		4				
	M20	G1/4	1		5				
Lever (Linear type)	10~80mm					1			
	70~150mm					2			
	Adapter type (30mm)				3			
	Adapter type (70mm)				4			
Lever (Rotary type)	M6 x 39L (Fork lever	type)			1			
	NAMUR type					5			
Ambient Temp.	-25~80°C						S		
	-40~80°C						L		
Communication	None							0	
	4-20mA Position tran	nsmitt	er					1	
	HART							2	
	HART with 4-20mA F	Positio	on tra	nsmit	ter			3	
Limit switch	None								0
(For TS700	Mechanical type								М
& TS705)	Proximity type								Р
	With dome cover (wi	thout	Limit	switcl	า)				D
Cable length	5m		· <u> </u>				· <u> </u>		1
(For TS720)	10m								2
	User define (Less tha	an 20	m)						Χ

2.7 Specification

Model		TS700	TS705		
Input sign	al	4~20mA DC			
Impedano	ce	500Ω (20mA DC)			
Supply pr	essure	0.15~0.8MPa			
Stroke		10~150mm(Linear typ	pe), 0~90º(Rotary type)		
Air conne	ction	PT1/4, NF	PT1/4, G1/4		
Gauge co	nnection	PT1/8,	NPT1/8		
Conduit		G1/2, NP	PT1/2, M20		
Explosion	proof type		IIC T5/T6 Gb Γ100°C/T85°C Db		
Enclosure)	IF	P66		
		-25°C∼+80°C (Standard type),			
	Acting Temp.	-40°C∼+80°C (Low temp type)			
Ambient	Explosion proof	-40°C∼+60°C (T5),			
Temp.	Temp.	-40°C~+40°C (T6)			
	LCD operating Temp.	-30°C~+85°C			
Linearity		±0.5% F.S.			
Sensitivity	/	±0.2	% F.S		
Hysteresi	S	±0.5% F.S			
Repeatab	ility	±0.3% F.S			
Air consu	mption	Below 0.01 LPM	l (Sup.=0.15MPa)		
Required	air quality	Class 4 (ISO8573-1)			
Flow capa	acity	Over 75 LPM (Sup.=0.15MPa)			
Material		Aluminum die cast	Stainless steel 316		
Weight		1.6 kg	4.0 kg		


Option specification

Option	Item	Specification
HART	HART version	HART 7
Position transmitter	Wire connection type	2 Wires
Position transmitter	Supply voltage	10~30V DC
Limit quitab	Mechanical type	OMRON D2F-LA AC125V, 3A, DC30V, 2A
Limit switch	Proximity type	P+F NJ1,5-F-N DC8.2V 8.2A

Note: Please contact our sales department for other specifications.


2.8 Structure

2.8.1 External structure



Note: ⑤ Dome indicator is only mounted on the product with limit switch option.

2.8.2 Internal structure




- ① PIEZO valve
- ② Button
- ③ Position transmitter module (Option)
- 4 PCB cover
- 5 Limit switch (Option)
- 6 Limit switch terminal block
- 7 Power terminal block

- 8 Feedback terminal block (Option)
- 9 Main PCB
- ① HART module (option)
- 11 Potentiometer


2.9 System configuration

Basically, the control valve system consists of a positioner for controlling the pneumatic pressure of the actuator, an actuator for controlling the opening of the valve, and a valve for controlling the flow of the fluid.




2.10 Principle of operation

TS700 receives 4-20mA input signal of the control room, micro-processor (CPU) compares input signal with position feedback through potentiometer and sends control signal to I/P conversion module torque motor, torque motor converts it to a pneumatic signal to controls PIEZO valve to controls the opening of the control valve by converting output pressure of OUT1 and OUT2.




2.11 Product Dimension


2.11.1 TS700 standard type



2.11.2 TS700 with limit switch type



2.11.3 TS700 feedback shaft



3 Installation

3.1 Before installation

∳ WARING

- Make sure if TS700 is appropriate to the valve and actuator installation conditions and the site requirements specifications before installation.
- If the installation state is not correct, TS700 control characteristics may be degraded.

3.2 TS700L installation


3.2.1 Notes on installation

When make the mounting bracket and connecting the lever to the stem connection pin, be sure to observe the following two points.

If failure to observe the followings, it will affect the product performance such as linearity.

NOTICE

- ① When the valve stroke is 50%, the feedback lever should be horizontal.
- When the valve stroke is 50%, the stem connection pin must be located at the numeric position marked on the feedback lever that is corresponding to the valve stroke.



- ① Feedback lever
- 2 Stem connection pin
- ③ Pin fixing spring

- 4 Actuator stem
- 5 Valve opening indicator


3.2.2 Effective rotation angle range of feedback lever

The effective rotation angle of TS700L lever is respectively 30° upward and downward that is based on horizon.

Follow 3.2.1 notes, effective rotation angle can be maintained to achieve the best performance.

№ NOTICE

- If the rotation angle range is too small during operation, the performance of products such as linearity may be degradation.
- If the rotation angle range is too big during operation, may damage the product or cause malfunctions.




3.2.3 Lever type and dimension

The numeric positions marked on the feedback lever correspond to the valve stroke, and the stem connection pin must be connected to the corresponding marked location.


Lever No.	Valve stroke	Dimensions
No.1	10~80mm	73.61
No.2	70~150mm	02 08 06 001 011 021 021 01 01 0S1 138.56
No.3	10~30mm (For the tube less type actuator)	35
No.4	10~70mm (For the tube less type actuator)	75 PL 07 07 09 09 02

3.2.4 Bracket Installation

Refer to the TS700L drawing (refer to 2.11.1) and actuator drawing, please make appropriate bracket and install the positioner on the actuator.



3.2.5 Dimension after installation




- ① Stem connection pin
- ② Feedback lever
- 3 Bracket

- 4 Actuator york
- ⑤ Lever adapter

3.3 TS700R installation


3.3.1 Rotary type installation examples



3.3.2 Rotary type bracket installation components

Components No.1~9 are provided with the brackets.

The brackets support the NAMUR mounting standard (VDI/VDE3835, IEC60534-6-2).



- ① Lower bracket(2)
- ② Upper bracket(1)
- ③ M6 nut(4)
- 4 Spring washer (4)
- ⑤ M6*15 bolt (4)

- 6 Fork lever type shaft lever(1)
- ⑦ NAMUR shaft adapter (1)
- M4 bolt(2)
- 9 M6*10 bolt(4)

3.3.3 TS700R installation steps

1	Install Lower bracket Attach two Lower brackets to the actuator and secure it with the bolts.	
2	Install Fork lever Install Fork lever to actuator's stem and tighten with the fixing bolt.	
	Decide the start point of Fork lever according to actuator stem's rotation direction.	
3	Tighten Upper and Lower brackets Combine Upper bracket and Lower bracket. Fasten with bolt, nut and spring washer.	
3	Tighten the bolts to the corresponding holes(H20, H30, H50) depending on the actuator stem height.	H20


№ NOTICE

- ②Main shaft and ①Indicator can be rotated 360°. When operating the product,
 ①Indicator must point ③Effective angle range.
- The product may not operate normally if ①Indicator points the opposite direction, so please consider the direction of ①Indicator when installing ④Shaft lever to ②Main shaft.

Install Shaft lever


Fork lever type

Install (4) Shaft lever to (2) Main shaft and tighten with (5) Bolt.




NAMUR type

Install ④NAMUR shaft adapter to ②Main shaft and fix it with two ⑤fixing bolts.



Install the product to Upper bracket and fix it with bolts.

5 At the moment, put the lever pin(the bottom of Shaft lever) to the hole of Fork lever, and align the center.



3.4 TS720 Remote type installation


TS720 is designed cable to the sensor part and the main body, it is designed to transmit the change of the stem position of the valve to the body through the potentiometer built in the sensor.

Application site

- Where the valve is located at high or inaccessible location.
- High temperature environment where is over than 85°C. (Non-explosion proof type only) (Maximume ambient temperature of the sensor part is 100°C)
- Large vibrating lines.

Installation

- 1 Install Sensor part on the valve, and install Body part on the accessible place.
- 2 Please follow the installation instructions of TS700L or TS700R for Sensor part's installation.
- 3 Sensor part and Body part are connected by the cable. (the length of cable must not over than 20m)
- OUT port of Body part should connect to the actuator using Pneumatic pipe.



- Sensor part
- ② Body part
- 3 Cable
- 4 Power cable
- ⑤ OUT1 piping

3.5 Option module Installation


According to the site requirements, the following modules can be purchased separately and installed.

NOTICE

- Please shut off the power supply and install the modules.
- Please connect ⑤Jumper when you install PTM.
- Please disconnect (5)Jumper when you install HART module or install HART and PTM both.

3.5.1 Position transmitter module(PTM) Installation


- ① Open the body cover and PCB cover, and install PTM to Main PCB as figure below.
- Please set feedback zero point settings and end point settings again after installed PTM. Please refer to page39 <OUT ZERO> and <OUT END> setting method.



- ① Fixing bolt
- ② Module Bracket
- 3 PTM
- ④ Main PCB
- ⑤ Jumper

3.5.2 HART communication module Installation


Open the body cover and PCB cover, and install HART module to Main PCB as figure below.




- Fixing bolt
- ② Module bracket
- 3 HART module
- (4) Main PCB
- 5 Jumper

3.5.3 Limit switch module Installation

There are two types of limit switch module, mechanical and proximity type.




<Mechanical type module>



<Pre><Pre>roximity type module>

Installation steps

- ① Open the cover.
- ② Install the limit switch module to PCB protective cover groove and fix it with fixing bolts.
- 3 Turn the camshaft and install it to the main shaft.
- 4 Fix the camshaft with fixing bolts.
- (5) Install the dome indicator to the camshaft.




- Dome indicator
- ② Bolt
- 3 Camshaft
- 4 Limit switch module
- ⑤ Module fixing bolts

Note

Standard product does not have a dome indicator window, so the cover also be replaced when you add limit switch module to the product.

3.5.4 How to adjust limit switch cam



The cam position is set at the factory. If you want to change the cam position, please follow the steps below.


- ① Open the cover and disassemble the dome indicator by referring to the above figure.
- 2 Loosen the fixing bolt slightly with a Phillips screwdriver, but do not disassemble it.
- 3 Adjust cam 3 and 4 by referring to the figure below, and adjust the angle so that the switch operates at the position you want.
- After adjusting the angle, fasten the fixing bolt tightly.

| Mechanical switch | Proximity switch |
|---|--|
| 3
5
4
2
1
1
1
3
5
4
2
1
1
2
1
2 | |
| Micro switch 1 Micro switch 2 Operating cam 1 Operating cam 2 Fixing bolt | Proximity switch 1 Proximity switch 2 Operating cam1 Operating cam 2 Fixing bolt |

How to replace Air filter 3.6


CAUTION

- Be careful when replacing the air filter as the valve may move. Please shut off the air pressure supplied to the positioner and replace the filter.



| Purpose | It protects internal PIEZO valve by removing foreign substances contained in the air supplied to the positioner. |
|----------------|---|
| How to replace | Loosen the fixing bolt with a flat-blade driver. Take out the inner filter, replace it, and fix it again with fixing bolt. When replacing the filter, please install O-ring well as shown in the picture above. |
| Note | Please check the filter periodically depending on the situation and replace it if necessary. If foreign matter adheres to the filter due to long-term use, it may affect the control performance of the product. Air filters can be reused by cleaning, but please replace the filter in case of oil contamination. |

3.7 Orifice installation




Purpose

A normal action product does not need to install the orifice, but if the hunting phenomenon occurs after installation on a small actuator, it can be solved by installing an orifice to reduce the output flow of air pressure transmitted to the actuator from the positioner. The hole size of the orifice is 1mm.

How to install

As figure below, Install the orifice into OUT1 port, and fix it by turning it all the way with a flat-bladed screwdriver.

- When using for single type actuator, please install orifice to OUT1 port only.
- When using for double type actuator, please install orifice to both OUT1 and OUT2 ports.



Note: Please contact us, if you need the above parts.


4 Pneumatic connection

4.1 Air pressure condition

⚠ NOTICE

- Use only dehumidified and dust-extracted compressed clean air.
- The air pressure input must be equipped with a regulator to supply constant air pressure.

4.2 Pneumatic port Description




- ① Supply port
- ② OUT1 port
- 3 OUT2 port
- ④ OUT1 gauge
- ⑤ OUT2 gauge

4.3 Air connection


№ NOTICE

• This product is designed to increase the air pressure of OUT1 as 4 ~ 20mA current input signal increases.

4.3.1 TS700L air connection



4.3.2 TS700R air connection





5 Electrical connection

♠ WARNING

- Check that the input current is within the product specification range. Exceeding the rating might cause a malfunction to circuit boards or burn out electrical components.
- Check polarity of + and exactly and connect wires.
- Separate the input current cable and the feedback signal cable correctly. Connecting
 the feedback signal cable to Power terminal for a long time may damage the main
 board.

5.1 Terminal description






- ① Input signal (+)
- ② Input signal (-)
- 3 Internal ground
- 4 Feedback signal (+)
- 5 Feedback signal (-)


- 6 External ground bolt
- (7) Conduit

5.2 Wiring diagram


5.2.1 Power and feedback signal connection



5.2.2 Mechanical Limit switch connection




5.2.3 Proximity Limit switch connection




6 Calibration

6.1 LCD description



| No. | Displayed contents | Description | | |
|-----|----------------------|---|---------------------|--|
| 1 | Menu information | Displays the running menu.
(Main menu, Main parameter, Sub parameter) | | |
| 2 | Menu value | Displays the present menu or parameter value. | | |
| 3 | Menu value unit | Displays the present menu's value unit. | | |
| | | PV | Progress value | |
| 4 | Menu value
symbol | sv | Signal value | |
| | | MV | Motor control value | |
| (5) | Progress bar | Displays the progress of the processor in bar form. | | |
| 6 | Main parameter | Displays the currently selected main parameter. | | |
| 7 | Parameter bar | Displays the position of the selected main parameter. | | |
| 8 | HART communication | The icon is displayed when HART communication is in progress. | | |
| 9 | Error code | The icon is displayed if there is an error during calibration or operation. | | |
| 10 | Save | The icon is displayed when changing the internal setting values such as parameter modification. | | |
| 11) | LOCK | The icon is displayed when the program is locked. | | |
| 12 | UNLOCK | The icon is displayed when the program is unlocked. | | |

6.2 Button description



- ① UP button
- ② DOWN button
- ③ ENTER button
- ④ ESC button

| Button | Function | Description | |
|--------|-----------|--|--|
| ENTER | confirm | Execute the functions of the selected menu. Save the modified parameter values. | |
| ESC | cancel | Move from the current menu to the upper level menu. Cancel the current command. | |
| UP | move up | Move between menus of the same level such as main menu, main parameter, sub parameter. Change the set value of the selected parameter to a larger value | |
| DOWN | move down | Move between menus of the same level such as main menu, main parameter, sub parameter. Change the set value of the selected parameter to a small value | |

6.3 How to quickly perform Auto calibration

Open the cover of product and follow below steps to perform Auto calibration quickly.

- ① Please input current signal **18mA**, then press **<UP>** button for 3 seconds.
- 2 The positioner automatically performs Auto calibration.
- 3 Auto Calibration is performed sequentially from STEP 1 to 7 on LCD, and may take 2-5 minutes depending on the valve size.



If an error occurs during Auto calibration, please refer to Error codes on page 49 to 50.

6.3.1 Auto calibration Steps

When you progress auto calibration, it automatically proceed in the following steps below.

| Steps | Description | | |
|-------|---|--|--|
| STEP0 | Check ZERO point of the valve speed. Check the reference point of valve stop. | | |
| STEP1 | Find ZERO point of the valve stroke. The valve position after all the pneumatic pressure of actuator chamber connected to OUT1 port is exhausted is recognized as ZERO point. | | |
| STEP2 | Find END point of the valve stroke. The valve position after the regulator setting pressure is supplied to actuator chamber connected to OUT1 port is recognized as END point. | | |
| STEP3 | Check the valve fully close time. Measure the time of the valve takes from full open to full close. | | |
| STEP4 | Check the valve fully open time. Measure the time of the valve takes from full close to full open. | | |
| STEP5 | Check the minimum valve movement Measure the motor signal reference value, when the position of valve at 25%. | | |

6.4 Software map

- To enter Main Parameter menu : Please input 4-20mA current signal and press **<ENTER>** button for 3 seconds after booting up.
- To enter Submenu : Press **<UP>** or **<DOWN>** button to select Main Parameter menu and press **<ENTER>** button.
- To select Submenu : Press **<UP>** or **<DOWN>** button.

| Main
parameter
menu | TUNNING | PARAMETR | DEVICE P | INFOMATN | DIAGNOST | EMERGNCy |
|---------------------------|----------|----------|----------|----------|----------|----------|
| | AUTO RUN | DEAD bND | ACTU SNG | FIRM VER | ERR CODE | PASSWORD |
| | AM FULL | AUTO OFF | ACTU LIN | DEVI REV | AUTO CHK | EMGY NON |
| | ACT NORM | PIEZO CL | FORCE OP | HART VER | PST RUN | FULL OP |
| | VAL OPCL | OP SIGTM | FORCE CL | dEid | PST CFG | FULL CL |
| | VAL ZERO | CL SIGTM | DAMP | POLL ADD | PST REDy | STOP |
| | VAL END | CONST OP | SPLT ZER | TRAVEL K | | UNLOCK |
| Submenu | OUT ZERO | CONST CL | SPLT END | OP TIME | | |
| | OUT END | START OP | COMPENSA | CL TIME | | |
| | IN ZERO | START CL | ACT NORM | TEMPERAT | | |
| | IN END | CHAR LIN | OUT NORM | TEMP MAX | | |
| | | USER DEF | HT NORM | TEMP MIN | | |
| | | | DSP NORM | | | |

6.5 Main menu description

After the product is booted, **<MAIN LIN>** is displayed, which shows the current opening of the valve. Press **<UP>** or **<DOWN>** button to move to the following menu and check the corresponding information.

In Main menu, information such as the valve opening and the magnitude of the input current signal can be checked and the execution of the command or the modification of the parameter value cannot be performed.

| Main menu | Description | | |
|------------|--|------------------------|--|
| | Display the percentage of current valve opening value. Depending on the set value of the flow characteristics, one of the following values is displayed. | | |
| | LCD display value | Flow characteristics | |
| MN_LN | MN_LN Linear | | |
| | MN_EQ1 | EQ1 (1/25) | |
| | MN_EQ2 | EQ2 (1/50) | |
| | MN_QO | Quick Open | |
| | MN_USR | User defined 17 points | |
| MAIN IN % | Display the magnitude of input signal that the positioner recognizes as percentage. If the size of the input signal recognized by the positioner differs from output signal of the DCS or calibrator, check the voltage of the power supply. If the supply current is normal, please reset <in zero=""> and <in end=""> settings in <tuning> of main parameter.</tuning></in></in> | | |
| MAIN IN mA | Display the magnitude of input signal that the positioner recognizes as mA. If the size of the input signal recognized by the positioner differs from output signal of the DCS or calibrator, check the voltage of the power supply. If the supply current is normal, please reset <in zero=""> and <in end=""> settings in <tunning> of main parameter.</tunning></in></in> | | |
| MAIN VEL | Display currently operating speed of the valve as numbers. As the value, between -2047 to +2048, negative numbers indicate speed at close, and positive numbers indicate speed at open. 0 means stop and the larger the absolute value, the faster the speed. | | |
| MAIN DEV % | Display the percentage of error between the current input signal and valve opening value. • The larger the error, the lower the control characteristic. | | |
| ABSP DIG | ABS Potentiometer Digit value Value converted to digital value by reading Potentiometer resistance value (range: 0 ~ 4095) | | |
| ABSP PER | ABS Potentiometer value in percentage Value in percentage converted to digital value by reading Potentiometer resistance value (range: 0% ~ 100%) | | |

6.6 Main parameter menu Description

Main parameter menu corresponds to main menu in which various parameters are classified by function.

- After the product is booted, press <ENTER> button for 3 seconds to enter Main Parameter menu.
- Main parameter menu is classified as below and can be moved by pressing <UP> or <DOWN> button.
- Press **<ENTER>** button in the corresponding menu to enter Submenu.

| Main parameter menu | Main function |
|---------------------|--|
| TUNNING | Run Auto calibration. Change Zero and Span of the valve manually. Change Zero and Span of feedback signal manually. |
| PARAMETR | Set Dead band.Change PID values.Change flow characteristics. |
| DEVICE P | Set Single/Double according to actuator type. Set Linear/Rotary according to actuator type. Set signal point of Force Open/Close. Set acting type. (Direct Action / Reverse Action) Set the valve acting speed. (DAMP) |
| INFOMATN | Display the product model. Display the device and HART version. Display Full Open/Close time. Display the current ambient temperature, the recorded maximum ambient temperature, and the recorded minimum ambient temperature. |
| DIAGNOST | Display the error code. Auto check function. Set PST function. |
| EMERGNCy | Set Password. In case of emergency, set function to forcibly open the valve, or close valve, or maintain current position. Set Lock and Unlock function. |

Submenu Description 6.7

The following is a detailed description of Main parameter menu's Submenu.

- Press **<ENTER>** button in Main parameter menu to enter Submenu. Use **<UP>** and **<DOWN>** button to move between Submenu.

6.7.1 **TUNNING**

| Submenu | | Description | |
|-------------|--|--|--|
| AUTO RUN | Run Auto calibration. Executable from any input signal between 4 and 20 mA. It takes 1~3 minutes, depending on the valve size. | | |
| | Select Auto calibration mode. | | |
| | Mode | Description | |
| | AM FULL | Set all parameter values again. | |
| АМ | AM WDTH | Reset MIMLO OP and MINHI CL values(which are PIEZO control characteristic parameters). | |
| | AM OPCL | Reset CONST OP and CONST CL values(which are PIEZO control characteristic parameters). | |
| | AM ZEb R | Only reset End point and Zero point of the valve, but the other parameter values are not modified. | |
| | Factory setting | AM FULL | |
| | Set the sensitivity of product. The setting value can be changed when hunting occurs due to a large friction of the valve stem or a small actuator size. | | |
| | Mode | Description | |
| ACT NORM | ACT SMLL | Select when actuator size is too small | |
| 7.5.7.1.5.1 | ACT NORM | Normal setting | |
| | ACT LAGR | Select when actuator size is too big | |
| | ACT FRIC | Select when the valve friction is too big | |
| | Factory setting | ACT NORM | |
| VAL OPCL | Regardless of the current signal, it performs the function of opening and closing the valve with <up></up> or <down></down> button manually. | | |
| VAL ZERO | Reset ZERO point of the valve manually. Input 4mA current, press <up></up> and <down></down> button to change the valve position, and press <enter></enter> button to save the current valve position, then the positioner recognizes the current position as valve ZERO point. | | |

| VAL END | Reset END point of the valve manually. Input 20mA current, press <up></up> and <down></down> button to change the valve position, and press <enter></enter> button to save the current valve position, then the positioner recognizes the current position as valve END point. |
|----------|---|
| OUT ZERO | Reset ZERO point of the feedback signal manually. Input 4mA current signal, valve reaches Zero position, after press < UP > or < DOWN > button to adjust the value, until the 4mA feedback signal is output, and then press < ENTER >button to save. |
| | NOTICE |
| | Please reset OUT ZERO setting after installing feedback module. |
| OUT END | Reset END point of the feedback signal manually. Input 20mA current signal, valve reaches end position, after press <up> or <down> button to adjust the value, until the 20mA feedback signal is output, and then press <enter> button to save. NOTICE</enter></down></up> |
| | <u> </u> |
| | Please reset OUT END setting after installing feedback module. |
| IN ZERO | Reset ZERO value of input signal manually. If <main in%=""> and <main ma=""> displayed at Main menu differ from the actual input signal, conduct the commands of this menu. Input 4mA current at this menu and press <enter> button twice to save.</enter></main></main> |
| | NOTICE |
| | After replacing the main board or conduct program initialization, please reset IN ZERO setting. |
| IN END | Reset END value of input signal manually. If <main in%=""> and <main ma=""> displayed in Main menu differ from the actual input signal, conduct the commands of this menu. Input 20mA current at this menu and press <enter> button twice to save.</enter></main></main> |
| | NOTICE |
| | After replacing the main board or conduct program initialization, please reset IN END setting. |

6.7.2 PARAMETR

| Submenu | Description | | | |
|----------|--|--|--|--|
| DEAD bND | Dead band range, the range of allowable control error. If hunting or oscillation occurs due to high packing friction of the valve, the problem can be solved by increasing the value within the range allowed by the field. If the value is set too high, the accuracy may be reduced. | | | |
| | Range | 0~10% | | |
| | Factory setting | 0.3% | | |
| AUTO OFF | | alue automatically during auto calibration.
s used, the value of above menu "DEAD nND" is | | |
| AUTO OFF | AUTO OFF | The Deadband value is NOT automatically set. | | |
| | AUTO ON | The Deadband value is automatically set. | | |
| | Factory setting | AUTO OFF | | |
| PIEZO CL | Display OFF time of PIEZO valve output current. If increase the time, can solve hunting or oscillation problem but positioner finds the target point slowly. If reduce the time, the positioner finds the target point quickly but it is more likely to happen hunting or oscillation. | | | |
| | Range | 1~500 | | |
| OP SIGTM | Display ON time of PIEZO valve output current when the valve open. If increase the time, the positioner finds the target point quickly but it is more likely to happen hunting or oscillation. If reduce the time, can solve hunting or oscillation problem but positioner finds the target point slowly. | | | |
| | Range | 1~500 | | |
| CL SIGTM | Display ON time of PIEZO valve output current when the valve close. If increase the time, the positioner finds the target point quickly but it is more likely to happen hunting or oscillation. If reduce the time, can solve hunting or oscillation problem but position finds the target point slowly. | | | |
| | Range | 1~500 | | |
| CONST OP | Display the proportional constant value of PIEZO valve output current to reach the target point when the valve open. If increase the value, can solve hunting or oscillation problem but | | | |
| | Range | 0.1~5.0 | | |
| CONST CL | Display the proportional constant value of PIEZO valve output current to reach the target point when the valve close. If increase the value, can solve hunting or oscillation problem but positioner finds the target point slowly. If reduce the value, the positioner finds the target point quickly but it is more likely to happen hunting or oscillation. | | | |
| | Range | 0.1~5.0 | | |

| START OP | Manually set the s
This value used v
reduce overshootii | vhen the valve is | s open | ing. If | | | | ed, can |
|----------|---|-------------------------------------|---|---|--|---|--|---|
| START CL | Manually set the s
This value used wh
overshooting prob | nen the valve is clem, but the spee | osing.
d of fin | If this va | | | ed, can | reduce |
| CHAR LIN | Set the characteris | R=50 | Input (mA) 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 | Linear (%) 0 6.25 12.5 18.75 25 31.25 37.5 43.75 50 56.25 68.75 75 81.25 87.5 93.75 | EQ1
(%)
0
2.55
3.26
4.16
5.32
6.79
8.67
11.07
14.14
18.06
23.06
29.45
37.61
48.02
61.32
78.31 | EQ2
(%)
0
1.31
2.81
4.54
6.55
8.92
11.73
14.76
18.26
22.58
27.93
34.55
42.73
52.85
65.37
80.85 | QO
(%)
0
29.13
46.84
57.21
64.56
70.27
74.93
78.87
82.28
85.29
87.99
90.42
92.65
94.69
96.59
98.35
100 | USER (%) 0 4 8 12 18 30 40 50 59 65 70 75 80 85 90 95 100 |
| | | CHAR LIN Linear | | | | | | |
| | | CHAR EQ1 | Equal percentage (1/30) | | | | | |
| | Mode | CHAR EQ2 | Equal percentage (1/50) | | | | | |
| | | CHAR QUI | Quick Open | | | | | |
| | | CHAR USR | User defined 17 points | | | | | |
| | Factory setting | CHAR LIN | | | | | | |
| | Run the special flow curve by user-defined 17 points. In addition to the above Linear, Equal percentage, Quick open and of typical flow characteristics, the user can set the 4~20mA corresponding valve stroke position to achieve special flow curve control. To run this function, <char usr=""> must be set at <char> menu.</char></char> | | | onding | | | | |
| | Steps | | | Descri | iption | | | |
| USER DEF | *USR P0 | Set the valve po | sition | when th | ne inpu | t signal | is 4 m | Α. |
| | *USE P1 | Set the valve po | sition | when th | ne inpu | t signal | is 5 m | A. |
| | *USR P2 | Set the valve po | sition | when th | ne inpu | t signal | is 6 m | A. |
| | *USR P3~16 | Follow above st input signal is 7 | eps for | setting | | | | |
| | *USR P17 | Set the valve po | | | ne inpu | t signal | is 20 r | nA. |

6.7.3 DEVICE P

| Submenu | Description | | | | |
|------------|---|-----------------|--|-------------|------------------------------|
| | Depending on the actuator type, it should be set to Single or Double manually. | | | | |
| | | | NOTICE ■ | | |
| ACTU SNG | If the setting differs for be degraded. | rom the | actuator typ | e, the con | trol characteristic may |
| 71010 0110 | | AC ⁻ | TU SNG | Single | type |
| | Mode | AC ⁻ | TU DbL | Double | e type |
| | | TS7 | 700L | ACTU | SNG |
| | Factory setting | TS7 | 700R | ACTU | DbL |
| | Depending on the acmanually. | ctuator t | type, it should | d be set to | Linear or Rotary |
| | | | ⚠ NOTIC | E | |
| ACTU LIN | If the setting differs for be degraded. | rom the | actuator typ | e, the con | trol characteristic may |
| | Mode | AC ⁻ | TU LIN | Linea | r type |
| | Mode | AC ⁻ | TU ROT | Rotary type | |
| | F | TS7 | 700L | ACTU LIN | |
| | | | 700R | | ROT |
| | When the input signal is higher than the set value, the valve is forced to open. This parameter is used to move the valve into its seat with the maximum force of the actuator. | | | | |
| | Valve Str | oke % | | | |
| | 100 | | | | |
| | | | / | | |
| FORCE OP | | / | | | |
| | 0 0 | | orce open set porce close set po | | Input Signal % |
| | Range | | 0~100% | | |
| | Factory setting | _ | TS700L | | 100% |
| | | | TS700R
When the | value set | 99.7% to 100%, this function |
| | Note | | is not appl | | to 10070, tillo lullottoll |

| 50005 O | forced to close. | nal is lower than the set value, the valve is sed, residual pressure in the actuator chamber eased. |
|-----------|---|--|
| FORCE CL | Range | 0~100% |
| | Factory setting | 0.3% |
| | Note | When the value set to 0%, this function is not applied. |
| | The higher the set value. | perating speed of the valve. ue, the slower the operating speed of the ting problem in small actuator can be solved. |
| DAMP | Range | 0~500 |
| | Factory setting | 0 |
| | Note | When the value set to 0, this function is not applied. |
| SPLIT ZER | Set Zero point of the signal value during the split range. For example, if the set value 50%, 12mA corresponds to of the valve opening as shoon the right figure. | e control. Jue is 0 0% Sown 100 100 100 100 100 100 100 1 |
| | Range | 0~100.0% |
| SPLIT END | Factory setting Set End point of the signal value during the split range For example, if the set value 50%, 12mA corresponds to of the valve opening as shown the right figure. | ue is 0 100% |
| | Range | 0~100.0% |
| | Factory setting | 100.0% |

| | This parameter corrects to opening. | the error betw | een LCD valu | ue and actual valve | | |
|----------|---|----------------------|------------------|-----------------------------|--|--|
| | | <u></u> МОТІ | CE | | | |
| COMPENSA | This function should only products must be set to 0 | | Linear type p | products and Rotary | | |
| | Range | -50.0~50.0% | | | | |
| | | TS700L(I | _inear type) | 3.0% | | |
| | Factory setting | TS700R(| Rotary type) | 0.0% | | |
| | Change the action mode | of the valve. | | 1 | | |
| | Reverse Actio | n | Direct Action | | | |
| | Valve Stroke% | | Valve Stroke% | | | |
| ACT NORM | 0
4mA 20m. | Input Signal mA
A | 0
20mA | Input Signal ma | | |
| | Mada | ACT NORM | l Rever | Reverse Action | | |
| | Mode | ACT REVE | Direct | Action | | |
| | Factory setting | ACT NORM | 1 | | | |
| | Change the output mode of feedback signal to the same percentage as the valve stroke, or the opposite percentage. | | | | | |
| | Normal | | | Reverse | | |
| OUT NORM | AmA Output Signal (mA | 20mA | Nalve Stroke (%) | A 4mA
Output Signal (mA) | | |
| | Mode | OUT NORM | 1 Nor | mal action | | |
| | | OUT REVE | Rev | erse action | | |
| | Factory setting | OUT NORM | 1 | | | |
| | Change the display mode HART communication. | e of the valve | opening trans | smitted through | | |
| HT NORMR | Mada | HT NORME | R Dire | Direct action | | |
| | Mode | HT REVER | Rev | erse action | | |
| | Factory setting HT NORMR | | _ | | | |

| | Change the display mode of the valve opening on LCD. | | | | |
|----------|--|---|--|--|--|
| | Mode | Description | | | |
| DSP NORM | DSP NORM | Displayed 0% on LCD when the valve is 0%, and displayed 100% on LCD when the valve is 100%. | | | |
| | DSP REVE | Displayed 100% on LCD when the valve is 0%, and displayed 0% on LCD when the valve is 100%. | | | |
| | Factory setting | DSP NORM | | | |

6.7.4 INFOMATN

You can find the following information through Submenu.

| Submenu | Description | | | |
|----------|---|--|--|--|
| FIRM VER | Display firmware version of the product. | | | |
| DEVI REV | Display the version of device. | | | |
| HART VER | Display the version of HART communication. | | | |
| dEid | Display HART Device ID number | | | |
| POLL ADD | Display Polling address of the device in HART communication. | | | |
| TRAVEL K | Display the accumulated total travel distance of the valve after the positioner has been used. (Unit: K%) One full travel distance from full close to full open means 100% = 0.001K% For example, if the travel value is 1K%, this means that the valve has moved 1000 stroke percentages. | | | |
| OP TIME | Display the time that takes from the valve fully close to fully open during Auto calibration. Unit: Second | | | |
| CL TIME | Display the time that takes from the valve fully open to fully close during Auto calibration. Unit: Second | | | |
| TEMPERAT | Display the current temperature in Celsius | | | |
| TEMP MAX | Display maximum temperature (update every 12 hours) | | | |
| TEMP MIN | Display minimum temperature (update every 12 hours) | | | |

6.7.5 DIAGNOST

| Self-diagnosis function of gear, pneumatic tube con Error code PNEUMATIC No product in the following production of gear, pneumatic tube con POTENMTR Main due to the following production of gear, pneumatic tube con POTENMTR Displatinstal production angle lever pleas production and product | code to resolve the problem. Depart Status of the product, internal nection, etc. Description Reumatic output to OUT port. Shaft gear and Potentiometer gear are dislocated external shocks, etc. Ty rotation angle of the lever of the product. ation problems do not occur frequently for Rotary ct. However, for linear product, the angle of the ct may be bigger or less than the effective 60°) depending on bracket and the position of connection. If displayed number is less than 40°, a refer to page 16-18 to correctly install the ct again. |
|--|---|
| POTENMTR AUTO CHK SIZE ANGLE PST RUN Gear, pneumatic tube cord PNEUMATIC POTENMTR Main due to list and product angle lever pleas product current affer ster accommended and production accord and production according to the production according to | Description eumatic output to OUT port. shaft gear and Potentiometer gear are dislocated external shocks, etc. y rotation angle of the lever of the product. ation problems do not occur frequently for Rotary ct. However, for linear product, the angle of the ct may be bigger or less than the effective (60°) depending on bracket and the position of connection. If displayed number is less than 40°, e refer to page 16-18 to correctly install the ct again. |
| PNEUMATIC No properties of the properties of the product of the pr | eumatic output to OUT port. shaft gear and Potentiometer gear are dislocated external shocks, etc. y rotation angle of the lever of the product. ation problems do not occur frequently for Rotary ct. However, for linear product, the angle of the ct may be bigger or less than the effective 60°) depending on bracket and the position of connection. If displayed number is less than 40°, e refer to page 16-18 to correctly install the ct again. |
| POTENMTR Main due to Displate Install production angle lever pleas production. COMPENSATE Run PST function accord affe ster according to the production according to th | shaft gear and Potentiometer gear are dislocated external shocks, etc. y rotation angle of the lever of the product. ation problems do not occur frequently for Rotary et. However, for linear product, the angle of the et may be bigger or less than the effective 60°) depending on bracket and the position of connection. If displayed number is less than 40°, e refer to page 16-18 to correctly install the et again. |
| AUTO CHK SIZE ANGLE Displatinstal production angle lever pleas production. COMPENSATE Run PST function according affective according to the production and the produ | y rotation angle of the lever of the product. ation problems do not occur frequently for Rotary ct. However, for linear product, the angle of the ct may be bigger or less than the effective 60°) depending on bracket and the position of connection. If displayed number is less than 40°, e refer to page 16-18 to correctly install the ct again. |
| SIZE ANGLE SIZE ANGLE Instal production angle lever pleas production according to the production angle lever pleas production. COMPENSATE Run PST function according to the production angle lever pleas production. Run PST function according to the production according to the production angle lever pleas production. Part affects the production angle lever pleas production. Set necessary items to expression and the production angle lever pleas production. | ation problems do not occur frequently for Rotary ct. However, for linear product, the angle of the ct may be bigger or less than the effective 60°) depending on bracket and the position of connection. If displayed number is less than 40°, e refer to page 16-18 to correctly install the ct again. |
| PST RUN PST RUN What is PST? Set necessary items to e | |
| PST RUN What is PST? Par affe ster accome eme | y the optimal compensation value based on the trotation angle. |
| PST RUN What is PST? affe ster acceemed Set necessary items to e | ing to the following PST CFG configuration. |
| | ial stroke testing (or PST), within the range of not cting to the flow process, PST prevents the valve in from sticking by moving the valve finely ording to the set value and the period. In case of rgency, it can make the valve operate normally. |
| PST CFG PST 1st START POINT1 POINT2 EMERGEN OCCUR | as follow. |

| | Submenu | | Description | | |
|----------|--------------------|---|---|--|--|
| | 0P POINT | Valve initial pos | Set the initial valve position for PST to start. Valve initial position must be within ±1% from "0S POINT". If not, wait until this condition is satisfied. | | |
| | | Default value | 100% | | |
| | | Range | 0~100% | | |
| | | Set 1st target p | osition of PST. | | |
| | 1S POINT | Default value | 90% | | |
| | | Range | 0~100% | | |
| | | Set 2nd target | position of PST. | | |
| | 2N POINT | Default value | 80% | | |
| | | Range | 0~100% | | |
| | | Set the waiting before the second | time after the first PST is end and and pond PST start. | | |
| | INTERVAL | Default value | 20 (Seconds) | | |
| | | Range | 1~100 (Seconds) | | |
| | LATENCY | Set the waiting time from "1S POINT" to "2N P start. After reaching the first target point "1S POINT" to the initial position, wait for "LATENCY" time specified by the user, and then move to the se "2S POINT" target point again. | | | |
| | | Default value | 10 (Seconds) | | |
| | | Range | 1~100 (Seconds) | | |
| | LMT TIME | If the time to re execution exce | owed to reach the target point. ach the target value during the PST eds "LMT TIME" time or there is no T is considered to have failed and PST interrupted. | | |
| | | Default value | 50 (Seconds) | | |
| | | Range | 1~100 (Seconds) | | |
| | | In PST process, if the valve position exceeds "EMERGNCY" set value, PST function is stopped. | | | |
| | EMERGNCY | Default value | 15% | | |
| | | Range | 0~100% | | |
| PST REDy | The following info | ction execution result value. formation is displayed on LCD based on the set value on results. See the table below to confirm PST executors. | | | |
| | | PST REDy | Doody to run DCT | | |
| | | FOINED | Ready to run PST. | | |

| | PST TOUT | "LMT TIME" failed to reach the target value within the set time value range. |
|--|----------|--|
| | PST FIXD | Valve has no action. |
| | PST DOUT | Exceed the target value more than 1%. |
| | PST EMRG | When allowable range of valve movement, i.e. "EMERGENCY" value is exceeded. |

6.7.6 EMERGNCy

| Submenu | Description | | | |
|----------|---|---|---------------------------|--|
| PASSWORD | Must put a password to enter this menu. The password is set at the factory and cannot be changed by the user. | | | |
| | Factory setting | Press UP > ENTER > DOWN > UP button sequentially. (1321 on LCD) | | |
| | Set the position of the valve to be moved when an abnormality of the positioner is detected. (If priority value of error code is "0") (refer to page 51) | | | |
| | Mode | EMGy NON | Do not take any action. | |
| EMGY NON | | EMGy OP | Open the valve fully. | |
| | | EMGy CL | Close the valve fully. | |
| | | EMGy STP | Stop the valve operation. | |
| | Factory setting | ng EMGy NON | | |
| FULL OP | Open the valve fully by manual regardless of the input signal. | | | |
| FULL CL | Close the valve fully by manual regardless of the input signal. | | | |
| STOP | Maintain the present valve position regardless of the input signal. | | | |
| UNLOCK | It locks to prevent changing all parameter values. When set to "LOCK", all commands such as Auto calibration, PID changes, and parameter values settings cannot be changed. | | | |
| | Mode | LOCK | Lock the program | |
| | | UNLOCK | Unlock the program | |
| | Factory setting | UNLOCK | | |

7 Error code and Troubleshooting

7.1 Error code during Auto calibration

- Error code as below is displayed on LCD if an error occurs during Auto calibration.
- Check the error code and refer to the table below to solve the problem.

| No | Error Code | Cause | Solution |
|----|------------|---|--|
| 1 | STEP0 V0 | Displayed when the valve does not stop after a long period of time when the data is measured to detect the first stop of the valve during auto calibration. And it is mainly caused by damage to Main board. | Replace Main PCB. |
| 2 | STEP1 PZ | Displayed when Zero point is lower than allowable range. | Check the status of the positioner installation or reinstall the positioner. Set initial angle (Zero point) of the lever higher than the current status. |
| 3 | STEP2 PE | Displayed when End point is higher than allowable range. | Check the installation status of the positioner or reinstall the positioner. Set final angle (End point) of the lever lower than the current status. |
| 4 | ACT TYPE | Displayed when Zero point and End point of the lever are too close or equal. | Check the status of supply air. Unplug the potentiometer cable in the positioner and reconnect it to Main board. Check the status of feedback lever installation. And set the operation angle that between initial angle(Zero point) and final angle(End point) over 40 degree. Replace Main PCB. |
| 5 | STEP3 CT | Displayed when Close time is too long during auto calibration. | Check the status of feedback lever installation. If Zero point of the valve changes, please conduct auto calibration 2~3 times. If the actuator size is too big, please set ACT mode as ACT LAGR and conduct auto calibration again. (Refer to page38) |

| | ı | I | T |
|---|----------|---|--|
| 6 | STEP4 OT | Displayed when Open time is too long during auto calibration. | Check the status of feedback lever installation. If the actuator size is too big, please set ACT value as ACT LAGR and conduct auto calibration again. (Refer to page 38) |
| 7 | STEP5 WD | Displayed when the positioner can't find the accurate position within the allowed time. | Check the status of feedback lever installation. If the actuator size is too big, please set ACT value as ACT LAGR and conduct auto calibration again. (Refer to page 38) |
| 8 | DEAD ZNE | Displayed when the feedback value of potentiometer is out of allowed range. | Check if the potentiometer is out of zero adjustment with the gear (vibration or external shock is the cause). Potentiometer is damaged. (please replace the potentiometer) |
| 9 | ERR | Displayed when auto calibration failed due to other unknown reasons. | Replace the positioner. |

7.2 Error code during operation

- If there is a problem during the operation, please enter "ERR CODE" which is Submenu of "DIAGNOST" to check the error code.
- Check the error code and refer to the table below to solve the problem.

| No | Code | priority | Cause | Solution |
|----|------|----------|--|--|
| 1 | L | 1 | Valve End point is set too high | Check whether the positioner is installed too high or low. Check whether the positioner is installed too far from the actuator. (Check the angle of use) Check the potentiometer gear and main gear are out of position. (The cause of the problem is strong vibration or external shock). |
| 2 | К | 1 | Valve Zero point is set too low | Check whether the positioner is installed too high or low. Check whether the positioner is installed too far from the actuator. (Check the angle of use) Check the potentiometer gear and main gear are out of position. (The cause of the problem is strong vibration or external shock). |
| 3 | J | 1 | Valve End and Zero
points are set too
close. (Use angle is
too small) | Increase the angle of use by repositioning the positioner closer to the actuator. |
| 4 | I | 1 | Input current is below 3.8mA | Check input current signal |
| 5 | Н | 1 | Input current is over 22mA | Check input current signal |
| 6 | G | 1 | BIAS value exceeds limit | Run Auto-Calibration again (Accuracy is significantly reduced when used without auto-calibration) |
| 7 | F | 1 | Ambient
temperature is too
high | Check ambient temperature |
| 8 | E | 1 | Ambient temperature is too low | Check ambient temperature |
| 9 | D | 1 | Used over 100,000 cycles | Check positioner regularly |
| 10 | С | 0 | Used over 500,000 cycles | Check positioner regularly |
| 11 | В | 0 | Used over 1million cycles | Replace positioner |
| 12 | Α | 0 | EEPROM is damaged | Replace PCB |
| 12 | A | 0 | EEPROM damaged | Replace main PCB |



Tissin Co.,Ltd.

201-1105, No 397, Seokcheon-ro, Bucheon-si, Gyeonggi-do, Korea 14449

Tel: +82-32-624-4573, Fax: +82-32-624-4574 www.tissin.co.kr

